

## Software


---

### Overview


To keep up with the ever changing market, the EX2000 series is field programmable to allow users to upgrade their software without the hassle of chip changes or board upgrades. All you have to do is connect your coin-op to your PC via the serial port, download your new software, and reprogram the EX2000 using ACDI's Bootloader software.

### Bootloader Instructions


- 1) Place the ACDI disk that came with your unit in to the CD-ROM drive of your pc.
- 2) Open the disk and double click on the "bootloader.exe" file, and the program will open in a new window.



- 3) Double click on the file path window, and a new window will open.
- 4) Locate your software file and double click to load.



- 5) Power down the EX2000
- 6) Press the Program HS12 button on the software



- 7) Press and hold the 1 on the EX2000 and apply power. Once the unit is powered up, release the button. The program will begin loading and will take a few minutes to complete. During the loading of the program this display of the EX2000 will have bars across it.
- 8) Once complete the software will reboot and the display will resume normal function.